

## NRAQ.E206327 Programmable Controllers

Page Bottom

## **Programmable Controllers**

See General Information for Programmable Controllers

## **DELTA ELECTRONICS INC**

E206327

31-1 SHIEN PAN RD KUEI SAN INDUSTRIAL ZONE TAOYUAN HSIEN, 333 TAIWAN

Communication interface units, Models DNA02, COA02, DVPEN01-SL, DVPCOPM-SL, RTU-485, RTU-DNET, ENA01-MOD, ENA01-EIP, DVPPF02-SL, RTU-PD01.

**Control modules**, DVP followed by 14, 16, 24, 30, 32, 20, 40 or 60, followed by ES, EX, SS or EC, may be followed by 2, followed by 00, 01, 10 or 11, followed by R, S or T, may be followed by additional suffixes.

DVP followed by 16, 20, 32, 40, 48, 60, 64 or 80, followed by EH, followed by 00, followed by R, T or M, may be followed by additional suffixes; DVP20PM00D, DVP20PM00M, DVP10PM00M may be followed by additional suffixes

DVP14SS11T, DVP14SS11R, DVP14SS11R2, DVP14SS11T2, DVP14SS11R.

DVP followed by 10 or 28, followed by SX or SV, followed by 11, followed by R or T; DVP followed by 12, 10 or 32, followed by SA, SC, MC or ES, may be followed by 2, followed by 11, followed by R or T; ELC followed by PC, followed by 12, followed by N, followed by N, followed by A, followed by R; Model DVP12SA10R may be followed by additional suffixes.

DVP followed by 14 or 20, followed by SS2 or SX2, followed by 11, followed by R, T or S, may be followed by additional suffix.

**Expansion I/O units**, DVP followed by 08, 14, 16, 24 or 32, followed by XM, XN or XP, may be followed by 2, followed by 00, 01 or 11, followed by R, N or T, may be followed by additional suffixes.

DVP followed by 02, 04, 06, followed by AD, DA, TC, XA or PT, followed by E2, may be followed by additional suffixes, rated 24V dc.

DVP followed by 08, 16, 32 or 48, followed by HN, HM or HP, followed by 11 or 00, followed by R, T or N, may be followed by additional suffixes; DVP followed by 01 or 02, followed by HC, followed by -H, may be followed by additional suffixes; Models DVP01PU-H, DVP06XA-H, may be followed by additional suffixes.

 $\textbf{Expansion modules}, \ \mathsf{DVP16SP11R}, \ \mathsf{DVP16SP11T}, \ \mathsf{DVP08SM11N}, \ \mathsf{DVP08SN11R}, \ \mathsf{DVP08SP11R}, \ \mathsf{DVP08SP11R},$ 

DVP followed by 01, 04 or 06, followed by AD, DA, PT, PU, followed by -S; Modules DVP06XA-S, DVP02DA-S, DVP08RT-S, DVP04TC-S; DVP followed by 06, 08, followed by SN, ST, followed by 11, followed by R, N; ELC followed by EX, followed by 08, followed by N, Models DVP08SM10N, ADP485-01, DVPDNET-SL, DVP16SM11N, DVP16SP11TS, DVP32SM11N, DVP32SN11TN, DVP02LC-SL.

DVP followed by PF or DT, followed by 01, followed by -S.

Model DOP followed by -EX, followed by IO, followed by 28 or 14, followed by R, followed by AE; Model DOP followed by -EX, followed by LN, followed by G, H or T, followed by J, followed by 1, 2 or 4, followed by AE.

Expansion unit, Model DVP followed by 04, followed by DA or AD, followed by -SL.

Hand held programmer, DVPHPPO followed by additional suffixes.

**Human machine interface**, Model DOP followed by -B, followed by 10, followed by S or E, followed by 615, may be followed by additional suffix.

Power modules, DVPPS01, DVPPS02.

**Programmable human machine interfaces**, Model TP followed by 02, 04, 05 or 08, followed by T or G, followed by A or B, followed by S, followed by 1 or 2; Models TP04G-AL-C, TP04G-BL-C.

DOP followed by -A or -AE, followed by 57, followed by G, C or B, followed by STD, may be followed by -W; Models DOP-AS57BSTD, DOP-A75CSTD, DOP-AE80THTD, DOP-AE80THTD0, DOP-A10THTD1, DOP-AE10THTD1, DOP-AE10THTD1, DOP-A10TCTD, DOP-AS38BSTD, DOP-AS38BSTD-W, DOP-B07S200, DOP-B05S100, DOP-B05S101, DOP-B07S201, DOP-B07S201A, DOP-B07S211, DOP-AS35THTD.

Models DOP-NP3 followed by -MQ, followed by 0 through 9, followed by 0 or 1, followed by 0 or 1, may be followed by B.

Models DOP-NP5 followed by -MQ or -SQ, followed by 0 through 9, followed by 0 or 1, followed by 0 or 1, may be followed by B.

**Programmable logic controller**, Model DVP followed by 10 through 60, followed by EC, followed by 00, followed by R or T, may be followed by additional suffix.

Pressure sensor, Model DPA01 or DPA10 may be followed by additional suffix.

Last Updated on 2010-07-22

Questions? Print this page Notice of Disclaimer Page Top

Copyright ?2010 Underwriters Laboratories Inc.®

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Listed and covered under UL's Follow-Up Service. Always look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Designs and/or Listings (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from the Online Certifications Directory with permission from Underwriters Laboratories Inc." must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "Copyright © 2010 Underwriters Laboratories Inc."

An independent organization working for a safer world with integrity, precision and knowledge.

